



## ActiveSync ® for Pocket PCs

ActiveSync ® for Windows allows you to connect your Hand Held or Pocket PC device to your desktop or laptop computer. When you are connected to your desktop or laptop, you can transfer files to and from either device. ActiveSync can be downloaded free from MicroSoft.com.



When you connect your device to your desktop or laptop PC with Microsoft ActiveSync installed, or run ActiveSync from your Programs, a window should appear as above. You can make adjustments to your serial port connection with your device by selecting “Connection Settings”.



When you select “Connection Settings” from ActiveSync, you can adjust your connection settings to your

## ActiveSync® for Pocket PCs


device. You can also remove your connection if it is interfering with another program or device, by unchecking “Allow serial cable.....”.



When you have made a connection with your PC and device, you will be asked if you want to set up a partnership. Generally, for Fpcom and FP1 work, you do not want to set up a partnership. You should select No.

## Flow Performance

# ActiveSync® for Pocket PCs



After your connection has been established between your device and your PC, you can run Windows Explorer and your device, along with all its files and folders, will appear on the Explorer file folder tree as “Mobile Device”.

You can access all the folders and files on your device through your PC Windows Explorer.

You will find the Fpcom.ppc files **Clear.txt**, **Quit.txt** and **Save.txt** in the Mobile Device folder “My Documents”. These files can be viewed and edited with NotePad or WordPad right from your desktop PC.